



Ordering Basic spec boards In PCB Artist

Basic spec boards require the customer to order through the PCB Artist software.

First make sure your board design is in "Basic Spec". Go to Settings>PCB Configuration to check.




The PCB Configuration is also where one can set up the board order. Verify Basic spec is suitable for your needs.

Pricing for Basic spec boards is found in the PCB Configuration.


Click Finish on the production section to save the changes in the PCB Configuration.

To order, click the Order Now link at the top of the software:



A gray box will pop to fill out.

Put in your log in information for Advanced PCB (AdvancedPCB.com).



Click Place Order.

If there are no errors, you will reach an upload page. Click the choose file button and navigate to your (filename) .pcb or newly created .fab file.

Once the file is selected, click the blue Upload button.

From here you'll be in the normal ordering system for Advanced PCB. Fill out payment, shipping and ITAR information and proceed forward with the order.